

How to insert a liner into a drum

The entire procedure will take approximately 10 seconds.



Take liner out of box.



Shake liner open.



Insert liner into drum.



Push liner down into drum.



Sides of liner will not be smooth.



Pull liner up to smooth out sides.



Sides of liner should be smooth and **CDF logo** should be centered in drum.



Lightly push the top of the liner down.



This is how the inside of your liner should appear.



CDF Corporation · 77 Industrial Park Road · Plymouth, MA · 02360
800.443.1920 · www.cdf1.com