

Air-Assist Regulator System attachment to the Air-Assist Liner

Below are instructions on how to attach the Air-Assist Regulator System to the Air-Assist Liner.



Air-Assist Regulator System



Fill tote normally, ensuring Air-Assist fill fitment is on top of bag.



Hang Air-Assist Regulator System on side of bin.



Attach plant air to Air-Assist regulator and attach camlock adapter to blue Air-Assist bladder fitting.



Turn on air supply.



Air-Assist will inflate; dispense as usual.



Close-up of inflating liner.



CDF Corporation · 77 Industrial Park Road · Plymouth, MA · 02360
800.443.1920 · www.cdf1.com