

How to dispense an Air-Assist Liner*

Below are instructions on how to dispense an Air-Assist Liner. Refer to “Venturi System attachment to Air-Assist Liner” for Venturi System set-up instructions.



Attach dispense attachment and air-assist attachment. Tote is ready for dispense.



Turn on air supply.



As air-assist liner inflates product is forced out of the form-fit liner.



Detail of air-assist liner inflating.



Air-assist liner will begin to stand as more product is forced out.



Detail of air-assist pressing product towards dispense.



Air-assist fully inflates to allow thorough dispense.



Air-assist liner evacuates product more completely than gravity flow.



Detail of product fully dispensed.

*Air-Assist Liner patent pending



CDF Corporation · 77 Industrial Park Road · Plymouth, MA · 02360
800.443.1920 · www.cdf1.com